

## AUDIOLOGIST INSTRUCTIONS

- 1.- Observe recognized procedures for otoscopic exam of the ear and be certain to screen the client's ear canal for contraindication.
- 2.- Insert an oto-block slightly beyond the second directional bend.
- 3.- We require the entire outer ear and down to the second bend of the ear canal.
- 4.- If using a Bite Block, require the patient to hold the jaw open about 1 inch while the impression cures.
- 5.- Use only silicone impressions material. Impressions will not be processed from powder and liquid type materials.
- 6.- Syringe the impressions material into the ear.
- 7.- Be sure to fill the canal up to the second directional bend and fill the concha completely.
- 8.- Be sure to over-fill the ear between the tragus and helix area.
- 9.- Provide ample time for the impressions to cure completely.
- 10.- Impressions must not contain cracks, ripples or voids.
- 11.- Carefully pack impressions in a crush resistant box and add the Information Form using only one form for each client.

## EAR MOLD IMPRESSION EXAMPLES

